



NOTES:

HEATER CONNECTION

1. WIRE BACK FROM THERMOSTAT IN 3 CORE FLEX TO 2 POLE SPUR SWITCH.
2. DISCONNECT LIVE CABLE FROM SWITCHED SPUR TERMINAL AND CONNECT ONE CABLE FROM STAT. CONNECT SECOND CABLE FROM STAT TO CONNECTOR.
3. CONNECT DISCONNECTED CABLE FROM SPUR TO TERMINAL.

TII PUBLICATION NUMBER: CC-SCD-01558

NOT TO SCALE